


# 指示器




## 压力&真空表

材料: 钢制外壳  
密封: 丁腈橡胶  
工作温度: -10°C至100°C

轴向安装



径向安装



型号	名称	接口	显示值
PA	轴向压力表	1/8" NPT	0 ~ 10 bar
PR	径向压力表	1/8" NPT	0 ~ 10 bar
PC	轴向压力表	1/8" NPT	0 ~ 6 bar
PH	径向压力表	1/8" NPT	0 ~ 6 bar
PZ	轴向压力表	1/8" NPT	0 ~ 4 bar
PS	径向压力表	1/8" NPT	0 ~ 4 bar
VA	轴向真空表	1/8" NPT	-1 ~ 0 bar
VR	径向真空表	1/8" NPT	-1 ~ 0 bar